

# SIMPLE SAVER SYSTEM® INSTALLATION INSTRUCTIONS

## BY THERMAL DESIGN

### RAFTER BRACE DETAILS

These fastening methods are routinely approved by building manufacturers for use with liner systems. Tip: Specify one of these options when ordering the building. If this is not possible, call the building manufacturer's engineering department for the number of fasteners needed to attach the braces or brace clips. These methods preserve the integrity of the high quality vapor retarder membrane. Brace clips (Detail A) are available from Thermal Design. Contractor is to verify the use of these connections with the building manufacturer. The manufacturer's standard method, if different from above, can be utilized but may require additional sealing materials.

Figure 1-14.

